

it is a manual state of the sta

RoHS Directive compatibility information http://www.mew.co.jp/ac/e/environment/

SLIM, SPACE-SAVING RELAY TERMINAL FOR 4-POINT OUTPUT

RT-3 UNIT RELAY (PA Relay type)

R S us

FEATURES

1. Space-saving type (33 mm 1.299 inch wide) with four independent points on a base measuring 33×67 mm 1.299 \times 2.638 inch. This contributes to a more compact control panel.

2. PA relays, which have high sensitivity Au clad twin contacts, are installed.

PA relays, 5 mm .197 inch wide, are installed. The PA relays feature high sensitivity (12 V type: 120 mW, 24 V type: 180 mW) and twin contacts with Aucladding, which combine to ensure high reliability even with minute loads. Can be mounted on a DIN rail or mounted directly (by screw).
Equipped with an LED display to allow easy confirmation of operation.
Incorporates a surge protector.
Incorporates an absorber circuit for coil surges. This protects the circuitry of the controller and prevents operation errors.
Relay installation and removal can be easily accomplished with the removal key accessory.
Includes a cover as standard equipment for increased safety.

TYPES

Contact arrangement	Rated input voltage	Part No.
1 Form A × 4	12 V DC	RT3S-12V
	24 V DC	RT3S-24V

Packing quantity: Carton: 1 pc.; Case: 20 pcs.

Notes: 1. Cannot be equipped with Power PhotoMOS standard type relays. However, equipping with voltage sensitive type of Power PhotoMOS relays (AQZOOOD) is possible.

2. 5 V DC units are also available. Please consult us.

3. Please inquire other contact arrangement.

RATING

1. Input ratings (per PA relay)

Part No.	Rated input voltage	Input current (at rated input voltage, 20°C 68°F) (approx.)	Allowable variation of rated input voltage (-20 to +55°C -4 to +131°F)
RT3S-12V	12 V DC	11.5 mA (Relay 10 mA + LED 1.5 mA)	12 V DC ± 10%
RT3S-24V	24 V DC	10.5 mA (Relay 7.5 mA + LED 3 mA)	24 V DC ± 10%

2. Relay coil specifications (per PA relay) (ref. value)

Relay part No.	Rated coil voltage	Pick-up voltage (at 20°C 68°F) (Initial)	Drop-out voltage (at 20°C 68°F) (Initial)	10% Coil resistance (±10%) (at 20°C 68°F)	Rated comsumption power
PA1a-12V	12 V DC	70%V or less of nominal voltage	5%V or more	1,200 Ω	120 mW
PA1a-24V	24 V DC		of nominal voltage	3,200 Ω	180 mA

3. Output ratings (per PA relay)

Specification	Item	Performance
Contact rating	Rated control capacity (resistive load)	3 A 250 V AC, 3 A 30 V DC
	Maximum allowable contact power (resistive load)	500 VA (AC), 60 W (DC)
	Maximum allowable contact voltage	250 V AC, 30 V DC
	Maximum allowable contact current	3 A
	Minimum load (ref. value)	100 mV 100 μA
Expected life	Electrical (resistive load)	
	Mechanical	Min. 2 × 107 (at 180 cpm)

SPECIFICATIONS

	Item	Specifications
	Between input and output	2,000 Vrms for 1 min.
Breakdown voltage	Between different terminals (between relays, both ways)	1,500 Vrms for 1 min.
Insulation resistance		Min. 100 MΩ (Using 500 V DC megger)
Vibration resistance (destr	uctive)	10 to 55 Hz at double amplitude 1 mm .039 inch
Vibration resistance (funct	ional)	10 to 55 Hz at double amplitude 1 mm .039 inch
Shock resistance (destruct	tive)	Min. 196 m/s ²
Shock resistance (function	al)	Min. 98 m/s ²
Ambient temperature		-20°C to +55°C -4°F to +131°F
Ambient humidity		35% to 85% R.H. (Not condensing)
Storage temperature		-30°C to +80°C -22°F to +176°F (Not freezing and condensing)
Terminal screw fasten torq	ue	0.3 to 0.5 Nm {3 to 5 kgf·cm}
Coil surge absorber		Diode (1 A, 400 V)
Cross connection protectin	ng diode	1.5 A, inverse voltage 40 V
Unit weight		Approx. 100 g 3.53 oz

Notes: 1. The value of breakdown voltage and insulation resistance is the initial one.

2. Condensing occurs when the unit relay is exposed to sudden temperature change in a high temperature and high humidity atmosphere. This may cause some troubles like insulation failure of the socket or the print circuit board. Take care under this condition

3. Below 0°C 32°F, condensing water can freeze and cause socket contact failures and other problems. Take care under this condition.

REFERENCE DATA

Maximum value for switching capacity (output)



DIMENSIONS (Unit: mm inch)



CAUTIONS FOR USE

1. Never install modules (relays) into this product other than those designated. Doing so will cause malfunction, breakdown, and breakdown of the connected product. 2. Physical Impact

If a unit is dropped be sure to check its external appearance and characteristics before using it.

3. The operation and return voltage values when equipped with PA relays are based on the relay terminals being face down.

4. Switching lifetime (PA relay)

This characteristic depends on the relay and is effected by coil driving circuit, load type, activation frequency, activation phase, ambient conditions and other factors.

Also, be especially careful of loads such as those listed below.

(1) When used for AC load-operating and the operating phase is synchronous, rocking and fusing can easily occur due to contact shifting.

(2) Frequent switching under load condition

When high frequently switched under load condition that can cause arc at the contacts, nitrogen and oxygen in the air is fused by the arc energy and HNO₃ is formed. This can corrode metal materials. Three countermeasures for these are listed here.

1. Incorporate an arc-extinguishing circuit.

2. Lower the operating frequency

3. Lower the ambient humidity

5. Operating environment

 Keep the product as far way as possible from power cables, high tension equipment, power equipment, equipment with transmitting devices such as amateur radios, or equipment which generates a large switching surge.
The main unit is made of resin; therefore, do not use it in areas where it may come in contact with (or be exposed to) organic solvents such as gasoline, thinner, and alcohol, or strong alkaline substances such as ammonia and caustic soda.

3) Do not use the product in areas where it may be exposed to flammable gases, corrosive gases, excessive dust, or moisture, or areas where it may be subjected to strong vibration or shock.

6. Installing and removing the module1) Firmly insert the module into the socket with the terminals going in the direction of the blade receptacles.2) The module can be easily removed using the removal key.

(1) Insert the removal key into the socket slots.



(2) Pull the removal key up to remove the module.



(3) Slide the removal key off of the module.



7. Wiring and circuit configuration

1) Perform wiring according to the internal schematic. Take care not to make any mistakes.

In particular, with the RT-3 relay (PA relay type) and 4-point terminal, be careful of the polarity on the output side when equipped with AQZ10*D (DC type). Also, with the RT-3 relay (Power PhotoMOS relay type), be careful of the polarity on the output side of the DC type (RT3SP1-**V for type equipped with AQZ102). 2) We recommend the use of wirepressed terminals for connection to the terminal portion.

• Example of applicable wire-pressed terminal

Company Name	Part Name	Applicable wire- pressed terminal
J.S.T. Mfg Co., Ltd.	1.25 to C3A	0.25 to 1.65mm ²

3) When the load is inductive, limit spike voltages generated from the load to less than the maximum load voltage. Typical circuits are shown below.

CAUTIONS FOR USE

Add a clamp diode to the load.



Add an R-C snubber to the load.

Output terminals



Add a varistor between the output terminals.



4) Even if spike voltages generated from the load are limited by a clamp diode or R-C snubber, inductances in long circuit wires will still create spike voltages. Keep wires as short as possible to minimize inductance.

8. Installation

 Perform mounting hole cutout according to the panel cutout drawings.
When installing the unit on a DIN rail, use the DIN rail locking lever on the side of the unit. Installation is accomplished by simply fitting the unit onto the rail and pressing gently.



3) To remove the unit from the DIN rail, use a flat head screwdriver to pull out the DIN rail locking lever.



CAUTIONS FOR USE

9. Transporting and storage

1) If the product is subjected to extreme vibration while being transported, the relays may become detached, the lead may become bent, and the unit may become damaged. Handle the inner and outer boxes with care.

2) If the product is stored in an extremely adverse environment, visible defects and deterioration of performance characteristics may result. We recommend the following storage conditions.

• Temperature: 5 to 30°C 41 to 86°F

- Humidity: Max. 60% R.H.
- · Environment: No hazardous substances such as sulfurous acid gases and little dust.

10. When equipped with Power PhotoMOS relay voltage drive type

Since the Power PhotoMOS relay voltage drive type does not require the currentcontrolling resistance on the input side, it can be used together with PA relays on RT-3 unit relay (PA relay type) or RT-2 relay terminals.

When connecting Power PhotoMOS relay voltage drive types, since it will be a close connection, it will be necessary to be careful of load currents. Be sure to refer to the information given regarding load currents and ambient temperature characteristics in the precautions given for use of RT-2 relay terminals.

TERMINAL BLOCK

We recommend using wire-pressed terminals for connection to the terminal portion.

- · Applicable electrical wire 0.25 to 1.65 mm² .01 to .065 inch
- · Applicable wire-pressed terminals



ACCESSORIES

Short circuit plate Use when you want to bridge terminals.





AY3802



General tolerance: ±0.5 ±.020

< Without insulator >

mm inch



AY3803



General tolerance: ±0.5 ±.020